


E-1

# DRX 50 Only Parts Book


Cylinder, Cylinder Head &amp; Spark Plug



Item	Part No.	Part Name	Qty	Note
1	12210-E06-010	Head Cover , Cylinder	1	
2	12251-E06-100	Casket , Cylinder Head	1	
3	12100-E06-010	Cylinder	1	
4	12191-E03-102	Gasket, Cylinder	1	
5	P91000-07109	Bolt, Stud	4	
6	P92120-07-10C	Hex. Acorn Washer Face Nut	4	
7	98069-BR8HSA-R	Plug, Spark	1	

E-2  
Piston, Crankshaft


# DRX 50 Only Parts Book



Item	Part No.	Part Name	Qty	Note
1	13000-E03-000	Crankshaft Ass'y	1	
2	95100-6204C3	Ball Bearing, Crankshaft	2	
3	96100-204208	Seal, Oil	1	
4	96100-203006	Seal, Oil	1	
5	13200-E03-000	Collar, L Crankcase	1	
6	95200-KBK10	Bearing, Needle	1	
7	13300-E06-000	Piston (std.)	1	
8	13400-E03-000	Pin, Piston	1	
9	13410-E03-100	Clip, Piston Pin	2	
10	13310-E06-000	Rings, Piston (std.)	1	
11	13010-E01-000	Key, Woodruff	1	


E-3  
Fan Shroud

# DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	17100-E06-000	Air Shroud , Cylinder	1	
2	17110-E01-000	Grommet	2	
3	18100-E04-000	Fan	1	
4	P91760-06016-05W	Hex. Socket Bolt	3	
5	P93100-06013-01W	Washer, Plain	3	
6	18210-E04-100	Cover, Fan	1	
7	P91825-05016	Screw, Tapping	1	
8	P93100-06013-01W	Washer, Plain	1	
9	18310-E04-000	Cover, Dust Protect	1	
10	P91825-06040	Screw, Tapping	1	
11	P91760-06020-05W	Hex. Socket Bolt	2	

E-4  
Oil Pump




Item	Part No.	Part Name	Qty	Note
1	15100-E01-000	Pump, Oil	1	
2	P93700-05016	Bolt, Pan, Crosshead	2	
3	94002-031108	Pin	1	
4	93406-STW19	Circlip	2	
5	15110-E01-000	Drive, Gear, Oil-Pump	1	




Item	Part No.	Part Name	Qty	Note
1	17300-P50-010	Air Cleaner Ass'y	1	
2	17332-P50-000	Joint, Air Cleaner	1	
3	17331-P50-000	Duct	1	
4	17310-P50-000	Cap, Air Cleaner	1	
5	97411-P50-000	Clip	2	
6	91825-A01-00A	Screw, Tapping	1	
7	14710-E03-000	Reed Valve Ass'y	1	
8	14711-E01-100	Gasket, Reed Valve	1	
9	16422-E01-000	Band, Intake Manifold	1	
10	16410-E01-000	Manifold, Intake	1	
11	P91760-06020-05W	Hex. Socket Bolt	4	
12	P91760-06020-05W	Hex. Socket Bolt	4	
13	17334-E01-00W	Water Shield K&N Style	1	
14	17300-P05-000	Air Cleaner With Base K&N	4	

# DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	16100-E03-030	Carburetor Ass'y	1	
2	16300-E01-000	Filter, Fuel	1	
3	16310-06135	Tube A , Fuel	1	
4	16310-06070	Tube , Fuel	1	
5	97410-E01-000	Clip, Tube	4	




Item	Part No.	Part Name	Qty	Note
1	11340-E03-000	Cover, L. Crankcase	1	
2	11395-E01-101	Gasket, L. Crankcase	1	
3	94001-081014	Pin, Dowel	4	
4	11344-E01-000	Shaft	1	
5	11200-E03-000	Crankcase, L.	1	
6	93507-082021	Bush	1	
7	11210-E01-000	Breather	1	
8	11211-E01-000	Hose, Breather	1	
9	P93101-E01-000	Washer, Copper	1	
10	91700-08012-12G	Hex. Washer Face Bolt	1	
11	96200-138024	O-Ring	1	
12	11212-E01-000	Plug, Oil	1	
13	11400-E01-000	Cover, Transmission	1	
14	11410-E01-000	Gasket, Transmission	1	
15	P91760-06020-05W	Hex. Socket Bolt	3	
16	P91760-06035-05W	Hex. Socket Bolt	10	
17	94001-101216	Pin, Dowel	2	
18	11100-E03-000	Crankcase, R.	1	
19	11110-E01-000	Holder	1	
20	P91760-06010-05W	Hex. Socket Bolt	1	
21	31121-E01-100	Gasket, A.C.G	1	
22	P91760-06025-05W	Hex. Socket Bolt	8	
23	P91760-06065-05W	Hex. Socket Bolt	1	
24	93506-123538	Bush	2	
25	17110-E01-000	Grommet	1	


# DRX 50 Only Parts Book



Item	Part No.	Part Name	Qty	Note
1	22110-E01-100	Wheel, Starter	1	
2	95200-555912	Bearing, Needle	1	
3	11213-E01-000	Boss	1	
4	P93100-55076-05B	Washer, Plate	1	
5	22100-E03-000	Wheel, Starter	1	
6	22120-E01-000	Idle Gear Ass'y	1	
7	11344-E01-000	Shaft	1	
8	P93100-08216-02C	Washer, Plate	2	
9	22121-E01-000	Plate, Idle Gear	1	
10	P91760-06010-05W	Hex. Socket Bolt	2	
11	28211-E01-100	Kick Shaft Ass'y	1	
12	28261-E01-000	Spring, Torsion	1	
13	28251-E01-000	Bush, Kick Shaft	1	
14	P93100-15228-01C	Washer, Plate	1	
15	93406-STW15	Circlip	1	
16	16105-A01-000	Kick Ass'y	1	
17	P91770-06025-10C	Hex. Bolt	1	
18	28221-E01-100	Kick Pinion Ass'y	1	




Item	Part No.	Part Name	Qty	Note
1	22300-E01-010	Secondary Clutch Assembly As	1	
2	22312-E01-000	Spring, Compression	1	
3	22331-E03-000	Spring, Clutch	3	
4	22330-E03-000	Carrier Ass'y, Clutch	1	
5	22332-E01-000	Nut, Clutch	1	
6	22340-E03-000	House. Clutch	1	
7	P92111-E01-000	Hex. Acorn Nut	1	
8	96200-125030	O-Ring	1	
9	22411-E03-100	Plate, Cam	1	
10	22412-E01-000	Slider, Cam Plate	3	
11	22413-P70-010	Weight Roller	6	
12	22410-P70-000	Sliding Sheave, Primary	1	
13	22414-E03-100	Collar	1	
14	22420-E03-100	Fixed Sheave, Primary	1	
15	22421-E03-100	Washer, Clam	1	
16	22422-E03-000	Clutch, One-way	1	
17	P93103-E01-000	Washer, Conical Spring	1	
18	P92110-10-17C	Hex. Acorn Nut	1	
19	22500-E03-000	Belt, Drive	1	
20	22400-E03-000	Sliding Sheave, Ass'y	1	



Item	Part No.	Part Name	Qty	Note
1	95100-638RD	Bearing, Ball	1	
2	96100-172855	Seal, Oil	1	
3	93406-STW17	Circlip	1	
4	95100-6003	Bearing, Ball	1	
5	23610-E03-000	Drive Gear, Primary	1	
6	P91760-06010-05W	Hex. Socket Bolt	1	
7	P93100-06519-12W	Washer, Plate	1	
8	P93104-E01-000	Washer, Conical Spring	1	
9	23620-E03-000	Main Axle Comp	1	
10	95100-6201	Bearing, Ball	1	
11	23630-E03-000	Gear, Driven	1	
12	95200-HMK2515-1	Bearing, Needle	1	
13	93405-IRTW32	Circlip	1	
14	96100-253506	Seal, Oil	1	
15	95100-6004LLU	Bearing, Ball	1	
16	93405-RTW42	Circlip	1	
17	23802-A01-000	Sprocket, Drive 18T	1	
17	23801-E01-000	Sprocket, Drive 19T	1	
17	23801-A01-00A	Sprocket, Drive 20T	1	
17	23801-E01-010	Sprocket, Drive 21T	1	
17	23801-E01-020	Sprocket, Drive 22T		
18	92130-14S-19G	Nut, Insert Lock	1	


E-11  
Generator

DRX 50 Only Parts Book



Item	Part No.	Part Name	Qty	Note
1	31120-E03-000	Base Ass'y, Generator	1	
2	P91760-06016-05W	Hex. Socket Bolt	2	
3	31100-E03-000	Wheel, Fly	1	
4	P93100-10022-20C	Washer, Plate	1	
5	P92110-10-17C	Hex. Acorn Nut	1	


E-12  
Start Motor



Item	Part No.	Part Name	Qty	Note
1	31200-E01-000	Starting Motor Ass'y	1	
2	P91760-06020-05W	Hex. Socket Bolt	2	


E-13  
Crankcase Bracket

DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	11347-E01-000	Bracket, Crankcase	1	
2	11348-E01-000	Shaft, Fix	1	
3	92130-08S-14G	Nut, Insert Lock	1	
4	96200-075015	O-Ring	1	
5	P92100-12040-14C	Hex. Bolt, Flange	1	
6	P92120-12-14C	Hex. Acorn Nut, Flange	1	

F-1  
Exhaust Pipe



Item	Part No.	Part Name	Qty	Note
1	12160-P70-010	(50cc & 90CC)-E Tuned Exhaust	1	
2	12161-A01-000	Washer, Muffler	1	
3	91811-A01-000	Bolt, Crosshead, Flange	2	
4	91700-10040-14G	Hex. Bolt, Flange	1	
5	92130-10S-14G	Nut, insert Lock	1	
6	P91760-0610-05W	Allen Screws	3	


# DRX 50 Only Parts Book



Item	Part No.		Part Name	Qty	Note
1	71000-A01-00F		Chassis	1	
1	71000-A01-070	2 A Arm	Chassis	1	
2	93405-IRTW32		Circlip	1	
3	95100-B6002 2RS		Bearing	1	
4	93205-A01-000		Cushion, Seat	2	
5	71205-A01-000		Engine Holder Seat	2	
6	93305-A01-000		Collar (anodized)	1	
7	93310-A01-000		Collar (anodized)	1	
8	91700-12220-14G		Blot Flange	1	
9	91710-08035-12G		Hex Washer Face Bolt	2	
10	91700-08012-12G		Hex Washer Face Bolt	4	
11	92130-12S-17G		Nut, Insert Lock	1	
12	31220-A01-011		Cable, Throttle	1	
13	71236-A01-000		VIN Plate	1	
14	91835-A01-000		Stud	2	


# DRX 50 Only Parts Book

## Awing Arm , Footrest



Item	Part No.	Part Name	Qty	Note
1	82105-A01-001	Fork, Rear	1	
2	95305-A01-000	Bushing Contain Oil	2	
3	93315-A01-000	Spacer Tube, Rear-fork	1	
4	93105-A01-100	Seal cover, swing Arm	2	
5	93210-A01-000	Rubber Sleeve	1	
6	91700-14290-19G	Bolt, Flange	1	
7	92130-14S-19G	Nut, Insert Lock	1	
8	91700-08012-12G	Hex Washer Face Bolt	8	
9	71215-A01-000	Footrest assembly	2	
10	93215-A01-000	Rubber Mate	8	


## Bumper A Arms



Item	Part No.	Part Name	Qty	Note
1	81105-A02-000	A. Arm, Left	1	
2	93505-A01-100	Bush	4	
3	95310-A01-000	Bush, rubber Oil, Top	2	
4	95315-A01-000	Bush, Rubber oil, Bottom	2	
5	81110-A02-000	A Arm, Right	1	
6	93605-A01-000	Waterproof Rubber	2	
7	93610-A01-000	Dustproof Rubber	2	
8	91700-10048-14G	Bolt, Flame	4	
9	92130-10S-14G	Nut, insert Lock	4	
10	91805-A01-000	Grease Valve	2	
11	71211-A01-00B	Front Bumper	1	
12	91700-08012-12G	Hex Washer Face Bolt	2	
13	91750-06016-10G	Bolt ,Flange	2	
14	71235-A01-010	Rear Hand Grip	1	


F-4A  
2A Arm

DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty
1	81105-A02-030	A. Arm, Upper,Left	1
2	81106-A02-000	A. Arm, Lower, Left	1
3	81110-A02-020	A Arm, Upper,Right	1
4	81111-A02-000	A Arm, Lower,Right	1
5	93507-082021	Bush	4
6	93505-A01-100	Bush	4
7	52316-A03-000	Ball Joint	2
8	93406-STW34	Cir Clip	2
9	91710-08035-12G	Hex Washer Face Bolt	4
10	91700-10048-14G	Hex Washer Face Bolt	4
11	92130-10S-14G	Nut, Insert Lock	8
12	P93100-10517-26G	Washer,Plate	4
13	P92140-10-14G	Cross Thread Nut	4
14	94000-02019	Cotter pin	4
15	71211-A01-020	Front Bumper	1
16	91700-08012-12G	Hex Waser Face Bolt	2
17	91750-06016-10G	Bolt ,Flange	2

## Fuel Tank, Oil Tank



Item	Part No.	Part Name	Qty	Note
1	12110-A01-000	Sponge	2	
2	12220-A01-001	Bracket, Support	1	
3	12210-A01-000	Gauge, Oil Level	1	
4	97411-A01-000	Clip	2	
5	12150-A01-020	Cap Assembly, Fuel tank	1	
6	12154-A01-100	Seal, Fuel Tank Cap	1	
7	12100-A01-020	Tank, Fuel	1	
8	12205-A01-001	Cap, Oil Tank	1	
9	12200-A01-001	Tank, Oil	1	
10	91750-06016-10G	Bolt ,Flange	2	
11	97410-A01-000	Clip, Tube	4	
12	12310-A01-001	Tube A , Fuel	1	
13	12311-A01-001	Tube B , Fuel	1	
14	12317-A01-011	Tube, Oil	1	
15	12105-A01-000	Valve, Fuel	1	
16	12215-A01-000	Oil Filter	1	
17	91700-06012-10G	Hex. Bolt, Flange	1	
18	91821-A01-000	Bolt, Hex Ladder Short)	2	
19	12151-A01-001	Hose, Breather (300mm)	1	
20	12153-A01-100	Spring	1	

## Shock Absorber, Lamp




Item	Part No.	Part Name	Qty	Note
1	81200-A01-200	Shock Absorber, Front 50%	2	
1	81200-A02-000	Shock Absorber, Front	2	
2	82200-A01-00A	Shock Absorber, Rear	1	
3	91710-10038-14G	Bolt, Flange	2	
4	91700-10040-14G	Hex. Bolt, Flange	2	
5	91770-10038-14G	Hex. Bolt	2	
6	92130-10S-14G	Nut, insert Lock	4	
7	62205-A01-000	Safety Light Comp	1	
8	62206-A01-000	Safety Light Bracket	1	
9	91825-A01-010	Philips Screw, Tapping	4	
10	62210-A01-000	Tail Light Comp	1	
11	93100-07020-01G	Washer, Plate	2	
12	92130-06S-10G	Nut, Self-Locking	2	

# DRX 50 Only Parts Book

F-7

Front Tire




Item	Part No.	Part Name	Qty	Note
1	24107-A01-000	Tire	2	
1	24105-A01-010	2 A ARM Tire (KENDA K532F) 20*6-10	2	
2	24205-A03-000	2 A ARM Rim 10*5.5	2	
2	24207-A01-100	Rim	2	
3	24106-A01-000	Valve, Tire	2	
4	96100-223507A	Seal, Oil	4	
5	95100-B6003 2RS		2	
6	93325-A01-100	Spacer, Inner	2	
7	31105-A01-000	Drum Brake, Front	2	
8	95100-B6002 2RS	Bearing	2	
9	93320-A01-100	Spacer, Outer	2	
10	93100-12540-45G	Washer, Plate	2	
11	92140-12-17G	Nut, Insert Lock	2	
12	94000-03032	Cotter pin	2	
13	93615-A01-000	Cap, Rubber	2	
14	92130-10S-14G	Nut, insert Lock	8	

F-8

# DRX 50 Only Parts Book


Rear Tire



Item	Part No.	Part Name	Qty	Note
1	24107-A01-000	Tire	2	
2	24207-A01-100	Rim	2	
3	23105-A01-001	Fixed bracket , Rim , Rear	2	
4	24106-A01-000	Valve, Tire	2	
5	93615-A01-000	Cap, Rubber	2	
6	92140-14-19G	Nut, Insert Lock	2	
7	93100-14540-45G	Washer, Plate	2	
8	94000-03032	Cotter pin	2	
9	92130-10S-14G	Nut, insert Lock	8	

F-9  
Drum Brake, Front

DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	31205-A01-001	Cable, Front Brake	2	
2	31306-A01-00A	Panel Comp., Front L. Brake	1	
3	31311-A01-00A	Panel Comp., Front R. Brake	1	
4	31315-A01-000	Brake Shoe, Front	2	
5	31320-A01-000	Cam Shaft, Front Brake	2	
6	31325-A01-010	Arm, Front L. Brake	1	
7	31330-A01-010	Arm, Front R. Brake	1	
8	91770-05024-08C	Bolt, Hex. Washer Plate	2	
9	97205-A01-000	Return Spring, Front Brake	2	
10	31305-A01-011	Panel Comp Ass'y , Front L. Br	1	
11	31310-A01-011	Panel Comp Ass'y , Front R. Br	1	

F-9B


# DRX 50 Only Parts Book

Drum Brake,Front



Item	Part No.	Part Name	Qty
1	31460-A03-000	Lever Ass'y,Right	1
2	31230-A02-000	Hose, Footbrake	1
3	91830-A01-000	Bolt, Brake Hose	3
4	93101-A01-000	Washer, Copper	6
5	91700-06016-10G	Hex Washer Face Bolt	1
6	31305-A03-000	Brake Disc,Front L.	1
7	31310-A03-000	Brack Disc,Front R.	1
8	91831-A03-000	Bolt, Brake Disc	6
9	31336-A03-000	Caliper Ass'y,Front Left	1
10	31335-A03-000	Caliper Ass'y,Front Right	1
11	P91710-08018-12G	Hex Washer Face Bolt	4
12	31337-A03-000	Brake Pad , Disk Brake	2


## Disc Brake System



Item	Part No.	Part Name	Qty	Note
1	31115-A01-000	Rear Disc Caliper	1	
2	31225-A02-000	Hose, Rear Disk Brake	1	
3	31300-A01-021	Rear Axle Bearing Carrier	1	
4	31335-A01-011	Rear Holder Disk	1	
5	95100-T6006ZZ	Bearing	2	
6	93330-A01-00A	Spacer	1	
7	96100-355511	Oil Seal	1	
8	96100-405507	Oil Seal	1	
9	31355-A01-020	Holder Disk	1	
10	31120-A01-000	Rear Brake Disc	1	
11	91760-10014-08G	Hex Socket Bolt	3	
12	91710-08038-12G	Hex Washer Face Bolt	2	
13	91710-12028-17G	Hex Washer Face Bolt	4	
14	91830-A01-000	Nut, Brake Hose	1	
15	93101-A01-000	Washer, Copper	2	
16	83115-A01-000	Clip, Brake Hose	1	
17	91700-06016-10G	Hex Washer Face Bolt	1	
18	92130-06S-10G	Nut, Self-Locking	1	
19	71220-A01-000	Rear Brake Guard	1	
20	91700-08012-12G	Hex Waser Face Bolt	2	
21	31116-A01-000	Brake Pad , Disk Brake	1	
22	31405-A01-000	Lever Ass'y,Left	1	


F-11  
Handle bar, Lever

# DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	51100-A01-010	Handlebar	1	
2	31450-A01-020	Lever Ass'y, Right	1	
3	51105-A01-000	Grip, Handle(L)	2	
4	61100-A01-010	Handle Switch Ass'y, Left	1	
5	52105-A01-000	Bottom Clamp, Handlebar	2	
6	52110-A01-000	Top Clamp, L. Handlebar	1	
7	52115-A01-000	Top Clamp, R. Handlebar	1	
8	92130-10S-14G	Nut, Insert Lock	2	
9	91760-06025-05G	Screw, Hex. Socket	4	
10	51110-A01-050	Pad, Handlebar	1	
11	52125-A01-00A	Fixed-bracket, Indicate light	1	
12	91760-06012-05G	Hex. Screw, Socket	2	
13	62105-A01-00A	Indicator Light, Oil(Red)	1	
14	31215-A01-000	Cable, Throttle	1	

Rear Axle, Sprocket




Item	Part No.		Part Name	Qty	Note
1	23205-A01-040		Wheel Axle, Rear	1	
2	P92110-28-36B		Hex. Acorn Nut	2	
3	23305-A01-00C	23305-A01-00A	Sprocket 35 alt # too	1	
4	23310-A01-000		Sprocket Holder, Driven	1	
5	91810-A01-000		Bolt, Hex. Washer Plate	3	
6	93103-A01-000		Spring Washer	3	
7	23300-A01-00C		Sprocket Ass'y (rear, 428-30T)	1	




Item	Part No.	Part Name	Qty	Note
1	23315-A01-100	Chain	1	
2	71225-A01-000	Guard, Bottom, Chain	1	
3	91815-A01-010	Adjuster, Chain m8	2	
4	91700-08012-12G	Hex Washer Face Bolt	5	
5	92130-08S-14G	Nut, Flange	4	
6	71230-A01-100	Guard, Top, Chain	1	
7	23320-A01-001	Bracket, Chain	1	
8	91823-A01-000	Hex Washer Ladder Bolt	1	

# DRX 50 Only Parts Book




Item	Part No.	Part Name	Qty	Note
1	52205-A01-000	Steering Shaft Ass'y	1	
2	52305-A01-100	Bolt, Stud	2	
3	52310-A01-100	Ball Joint, Left Thread	1	
4	52315-A01-100	Ball Joint, Right Thread	1	
5	52320-A01-000	Knuckle, L.	1	
6	52325-A01-000	Knuckle, R.	1	
7	52120-A01-000	Shaft Holder, Steering	2	
8	93510-A01-000	Bush, PU	1	
9	96100-183207A	Seal , Oil	1	
10	93325-A01-100	Spacer, Inner	1	
11	96100-223507A	Seal, Oil	1	
12	92141-10-14G	Cross Thread Nut	2	
13	92130-08S-14G	Nut, Insert Lock	2	
14	92130-14S-19G	Nut, Insert Lock	1	
15	92130-10S-14G	Nut, insert Lock	4	
16	94000-01620	Cotter pin	6	
17	94000-03032	Cotter pin	1	
18	52300-A02-100	Link Ass'y	2	




Item	Part No.	Part Name	Qty
1	52205-A01-020	Steering Shaft Ass'y	1
2	52320-A03-000	Knuckle, L.	1
3	52325-A03-000	Knuckle, R.	1
4	P93107-21228-10	Washer, Plain	2
5	52120-A01-000	Shaft Holder, Steering	2
6	93510-A01-000	Bush, PU	1
7	96100-183207A	Seal , Oil	1
8	93325-A01-100	Spacer, Inner	1
9	96100-223507A	Seal, Oil	1
10	92130-08S-14G	Nut, Insert Lock	2
11	92130-14S-19G	Nut, Insert Lock	1
12	92130-10S-14G	Nut, Insert Lock	4
13	94000-01620	Cotter pin	4
14	94000-03032	Cotter pin	1
15	52300-A02-010	Link Ass'y	2

# DRX 50 Only Parts Book



Item	Part No.	Part Name	Qty	Note
1	63100-A01-002	Main Wire Assy	1	
2	63205-A01-00A	Battery	1	
3	61105-A01-001	Main Switch	1	
4	61107-A01-000	Clip, Main Switch	1	
5	91732-06015G	Bolt	1	
6	83110-A01-000	Rubber Band,Tool Bag	1	
7	61115-A01-010	C.D.I Unit	1	
8	61120-A01-000	Rectifier & Regulator	1	
9	61125-A01-100	Resistor	1	
10	61130-A01-100	Starter Relay	1	
11	61109-A01-000	Ignition Coil	1	
12	72105-A01-000	Tool Bag	12	
13	93705-A01-000	Strap	2	
14	91740-05012G	Bolt, Pan Phillips	3	
15	91700-06016-10G	Hex Washer Face Bolt	2	
16	91700-06012-10G	Hex. Bolt, Flange	1	
17	83105-A01-010	Rubber Band, Battery	1	
18	72117-A01-010	Owner manual	2	
19	97810-A01-000	Bag for Manual		

## DRX 50 Only Parts Book



Item	Part No.	Part Name	Qty	Note
1	71305-A01-00B	Seat	1	
2	72205-A01-000	Fender, Front(blue)	1	
	72205-A01-00A	Fender, Front(Red)	1	
	72205-A01-00B	Fender, Front (yellow)	1	
	72205-A01-11C	Fender,Front(silver)	1	
	72205-A01-00F	Fender,Front(green)	1	
3	72210-A01-000	Fender, Rear (blue)	1	
	72210-A01-00A	Fender, Rear (Red)	1	
	72210-A01-00B	Fender , Rear(yellow)	1	
	72210-A01-11C	Febder,Rear(silver)	1	
	72210-A01-00F	Febder,Rear(green)	1	
4	72215-A01-000	R. Footrest	1	
5	72220-A01-000	L. Footrest	1	
6	91750-06016-10G	Bolt ,Flange	2	
7	72115-A01-060	Graphic Sticker	1	
8	72110-A01-060	Sticker,Warning	1	
9	72110-A01-050	Sticker,Warning	1	
10	72110-A01-030	Sticker,Warning	1	
11	72110-A01-040	Sticker,Warning	1	
12	91700-06016-10G	Hex Washer Face Bolt	8	
13	91825-A01-00A	Screw, Tapping	16	
14	92215-A01-000	U Plate Nut	16	
15	92210-A01-000	U Plate Nut(Andoised)	4	
16	91765-06018-04S	Hex Socket Bolt	2	
17	91821-A01-000	Bolt, Hex Ladder(Short)	2	
18	91820-A01-000	Bolt, Hex Ladder(Long)	2	
19	92130-06S-10G	Nut, Self-Locking	8	
20	72120-A01-000	Heat Cushion(Side)	1	
21	72125-A01-000	Heat Cushion(Front)	1	
22	72130-A01-000	Heat Cushion(Rear)	1	
23	93104-A01-010	Washer, Nylon	16	

## DRX 50 Only Parts Book

Page	1 Cylinder, Head & Gaskets
Page	2 Piston & Crankshaft
Page	3 Fan Shroud & Oil pump
Page	4 Air Cleaners & Reeds
Page	5 Carburator
Page	6 Crankcase
Page	7 Kick starter and starting gears
Page	8 Clutch and slide face
Page	9 Transmission
Page	10 Generator & Starter
Page	11 Crankcase bracket & Exhaust Pipe
Page	12 Frame
Page	13 Swing Arm & footrest
Page	14 Bumper and A-Arms
Page	15 Bumper and 2 A-Arms
Page	16 Fuel tank & oil Tank
Page	17 Shocks and lighting options
Page	18 Front Tire
Page	19 Rear Tire
Page	20 Front brakes
Page	21 Front brakes 2 A Arm
Page	22 Rear brakes
Page	23 Handle bar & controls
Page	24 Rear Axle
Page	25 Chain and Guards
Page	26 Steering components
Page	27 Steering components 2 A Arm
Page	28 Electrical
Page	29 Body and seat